



FLEXI 2R (USB-C)

10.01.171.XY/USB-C X: 4  8  Y: 1  2  8 



FLEXI 2R

10.01.171.XY X: 4  8  Y: 1  2  8 

