

# FLEXI 2R

# FLEXI 2R (USB-C)

10.01.171.XY

X: 4 ● 8 ●

Y: 1 ○ 2 ○ 8 ○

10.01.171.XY/USB-C

X: 4 ● 8 ●

Y: 1 ○ 2 ○ 8 ○

