

TOUCH SWITCH FOR MIRROR

10.05.09/CW

Y:10/10 | ON/OFF





10.05.09/CW/DIM

Y:10/10 |  ON/OFF

10.05.09

Y:3/4 |   ON/OFF**Ver. A
LED**

10.05.09/4LED

**Ver. B
4LED****Ver. A
LED****Ver. B
4LED****12V
DC**

TAPE WW-CW	/	TAPE WW/NW/CW
ON/OFF	and	DIMBLE