

FLEXI H / FLEXI RH

10.01.105.XY/RH/USB-C

X: 9 10 11 12 13 14 15 Y: 1 0 8 0

